

User's Guide

EnergyCenter®

Keilton+autani Capabilities

Table of Contents

	-0		
2.	Inter	Interacting with Lights	
		General (On-Demand Changes)	
	2.2.	Charts	6
	2.3.	Event Logs	6
	2.4.		
	2.5.	Group (On-Demand Changes)	7
3.	Viewing Energy Consumption/Estimation		9
		3.1.1. Energy Consumption Reports	11
		3.1.2. Energy Usage	11
		3.1.3. Energy Configuration	12
4.	Creating and Using Views		13
		Setting up a View	
	4.2.	Adding Devices from a Group	14
	4.3.	Adding Devices Individually	15
	4.4.	Interacting with Lights	16

Register a New Account on Autani Portal.....


Autani LLC

7001 Columbia Gateway Drive, Suite 210, Columbia, MD 21046 USA (443) 320-2233 | (240) 755-0092 (fax) | www.autani.com


This document contains the Proprietary and Confidential Information of Autani, LLC. Any use of this information without the expressed written consent of Autani, LLC is prohibited. Copyright Autani, LLC 2010-2025. All rights reserved. Please refer to www.autani.com/legal for licensing, intellectual property, and other legal notices and information.

1. Register a New Account on Autani Portal

 Open a browser on your computer and enter https://portal.autani.net/ in the address bar, and then press the enter key. The Autani splash screen is displayed with the Login and Register buttons. Click on the Register button to Create a New Account.




The Register form is displayed. Enter your Name, Email, Phone Number, Password and re-enter your Password. Then click on the REGISTER button to proceed further.




3. Now Re-Login to the portal using the new credentials: Click on your name in the top right, click on Log Out, then click on User Login.



4. NOTE: The initial association of your system is already done by Autani. The Dashboard has a list of systems displayed. Click/tap on the Launch button of your system to log in to EnergyCenter[®].




 When the EnergyCenter® Login screen appears, enter the default login credentials (Username: admin, Password: password), and click on Login.




2. Interacting with Lights

 To interact with lights through EnergyCenter®, click on Devices section, the Dashboard page is displayed by default. Click on the Lights tab to start the integration process.




- 2. The Lights tab lists all the lights in your system.
 - The Location column is the identifier for the Lights from the Keilton App. It has both Group and Zone (example: Office – LEDucationDemoBox01).
 - The Zone represents a Bluetooth network, and one Zone corresponds to one single CR05. One CR05 can communicate with 100 lights within proximity.




General (On-Demand Changes) 2.1.

Select the Light you need to integrate with EnergyCenter®. Click on the Light code inline or click on the Details tab at the bottom.




4. The Lights-Detail window opens with the General tab selected by default. Here you can make on-demand changes to the light, like switching the light ON/OFF and changing the luminance levels of Occupied/Unoccupied states. Click Apply to save changes.




2.2. Charts

Select the next tab Charts for the selected light and edit the date range to view the light's behaviour over that period of time.



2.3. Event Logs

Select the Event Logs tab to see the light's events. Edit the date range to view the light's events over that period of time.



2.4. Notes


7. Select the next tab **Notes**, wherein you can leave a note for other users to refer to. (Example: This Light was commissioned ..., this is light does not support... etc.,)




2.5. Group (On-Demand Changes)

Groups section is another place, where the on-demand changes can be made to a group of lights/devices.

- To interact with lights through Groups, click on the Groups section of EnergyCenter®, the
 page will load the Groups tab by default, with the list of the existing Groups.
- 2. From the List of the groups click on a group name.



The Group Summary window opens. Here you can make on-demand changes to all the lights in the group. Change the percentage of luminance/intensity of the lights and click on the Apply button.




3. Viewing Energy Consumption/Estimation


- There are two ways to view Energy Consumption: one is through the **Devices** section and the other through the **Groups** section of the EnergyCenter® software.
- To view the device-based energy estimation, click on the Devices section and then click on the Lights tab. All the lights will be listed.

On the top right, click on "Show/Hide Energy" link, and the Energy Usage chart is displayed (if hidden, or vice versa) in the lower section.


- The **KWh** column displays the Energy usage of each light.
- The Display column is used to select or deselect light(s).
- Use the **Date** field to select a date range to view the energy estimation.



- To see group-based energy consumption, click on Groups. On the top right, click on "Show/Hide Energy," and the Energy Usage chart will be displayed below the list of groups.
 - The KWh column displays the Energy usage of each light.
 - Use the **Date** field to select a date range to view the energy estimation.




4. From the List of the groups click on a group name. The **Group Summary** window opens.



3.1.1. Energy Consumption Reports

 To view the Energy Consumption Reports, click on the Analysis section of the EnergyCenter® software, and various categories of reports for the lights will be listed. Click on each kind to see the respective report data.




3.1.2. Energy Usage

 Another place to view the Energy Usage is the Energy section of the EnergyCenter® software. Click on the Energy section to view the data.



3.1.3. Energy Configuration

To configure the Energy estimation suite in a global region, use the Settings section.
 Select Settings and click on the Energy tab. All Energy data settings will be listed and can be modified per the requirement.




4. Creating and Using Views

Another capability of EnergyCenter® is to use the **Views** tab in the **Groups** section to configure the Lights.


4.1. Setting up a View

This section will talk about uploading the image file to get started with setting up your view to plot points.

 Select the Groups section and then select the Views tab. The page will be blank if no group-views are available, or the page will display a previously selected group-view.




- 2. The interface has both horizontal and vertical elements to create or modify a view.
 - A. The **Group Dropdown** is used to select a Group.
 - B. The Views Dropdown will allow you to add, edit, or delete a view to a group.
 - C. The Group Add button is used to add a device to the view. There is another button Marker to add the devices.
 - D. Existing device markers added to the view.




4.2. Adding Devices from a Group

 To add a device, click on the "Group Add" button. When the "Group Add" window opens, select a group from the dropdown. The devices of the group will be displayed. Click and drag each device onto the view.




4. The device marker is added to the product. Click on the **marker**, and then click on the device link to configure the device.




4.3. Adding Devices Individually


3. **OR**, the other method to add a device is to click on the **OR** Marker button and place it on a device. In this case, the 8-button **Switch** has been added, placing the marker on the **OR** button.



 When you click on a device location, the Select a Device window opens. Select a device to associate with the marker and click on the Save button.




The device marker is added to the product. Click on the marker, and then click on the device link to configure the device.




4.4. Interacting with Lights


 The Lights-Detail window opens with the General tab selected by default. Here you can switch the light ON/OFF and change the luminance levels of Occupied/Unoccupied states. Click Apply to save changes.



Select the next tab Charts for the selected light and edit the date range to view the light's behaviour over that period of time.



8. Select the **Event Logs** tab to see the light's events. Edit the date range to view the light's events over that period of time.





Autani LLC

7001 Columbia Gateway Drive, Suite 210, Columbia, MD 21046 USA (443) 320-2233 | (240) 755-0092 (fax) | www.autani.com

This document contains the Proprietary and Confidential Information of Autani, LLC. Any use of this information without the expressed written consent of Autani, LLC is prohibited. Copyright Autani, LLC 2010-2025. All rights reserved. Please refer to www.autani.com/legal for licensing, intellectual property, and other legal notices and information.