

**1**

Each Autani T-32-P Thermostat is listed on the provided list of device serial numbers. Note the specific thermostat to which the Indoor Remote Temperature Sensor will be wired.

SN: AXXXXXXXXX

**EXAMPLE**

**2**

Select a location for the sensor that represents the ambient space temperature to be controlled.

**AVOID:**

- Areas where drafts are present, air movement is limited, or that are affected by direct sunlight.
- External walls and locations near the floor or behind doors.

**CAUTION:**

- Shielded cable must be used if wiring is within one foot of large inductive loads such as motors, line starters, lighting ballasts, and large power distribution panels.
- Sensor cables should not be routed with line voltage power wires, or near control contactors, light dimming circuits, electric motors, or welding equipment.

**3**

Pry the sensor cover from the backplate.

**4**

Pull the sensor cable through the wire access hole on the backplate.

**5**

**MOUNT THE SENSOR.**

1. Mark the locations for the mounting screws.
2. Drill holes for the mounting screws.
3. Screw the sensor backplate to the wall.

**6**

Connect the sensor cable to the screw terminals located on the board in the sensor.

For temperature averaging, multiple sensors can be connected. For more information, see the back side of this installation sheet.

**7**

Seal the wire access holes in the backplate and the wall to prevent any drafts that might affect the sensor.

**8**

Snap the sensor cover back onto the backplate.

**9**


For additional information, see the back of this sheet, the Autani T-32-P Thermostat Quick Installation Guide, and the Autani Integrated Wireless T-32-P Thermostat Installation Guide.

Mutliple remote sensors can be connected for temperature averaging. The sensors are wired in series/parallel so that their total value always equals 10KΩ.


**NOTE: If the internal sensor in the Autani T-32-P Thermostat is used as one of the temperature averaging points, it is not part of the equation but will always represent 50% of the total averaging value.**

For additional information, see Autani T-32-P Thermostat Quick Installation Guide and the Autani Integrated Wireless T-32-P Thermostat Installation Guide.


**1 Remote Sensor**



**9 Remote Sensors**




**4 Remote Sensors**



**SERIAL NUMBER INFORMATION AND TRACKING**

The serial number or ID of a device is used to track device installation locations and details for the commissioning process. The identification information for each device should be tracked in a meaningful way, many devices include duplicate 'stickers' with this information. Autani provides an iOS app to assist with the process.



For help getting starting with the iOS Commissioning App please see Autani's User Guide for the iOS Commissioning App.



Once commissioning details are collected, either through the iOS Commissioning App, or by tracking identifiers on drawings/spreadsheets. Please provide this information to support@autani.com to begin the commissioning process.